


REVISIONS

REV	DESCRIPTION	ECO	DATE	DWN	APVD
A	Initial Release		8/31/2016	BB	AR
B	Changed strain relief boot, added part ID table	00339	3/21/2019	BB	WN


- NOTES:**
- SUITABLE FOR .5mm OR .25mm POF WITH 1mm JACKET (SEE TABLE)
  - TIGHTEN HEX NUT TO 8 IN-LBS (0.9 N-m) MAX




- INSTRUCTIONS:**
- STRIP 6mm OF JACKET FROM FIBER.
  - SLIP BOOT OVER CABLE JACKET.
  - APPLY EPOXY TO BARE FIBER AND INSERT INTO CONNECTOR; ROTATE FIBER DURING INSERTION TO EVENLY DISTRIBUTE EPOXY.
  - SLIP BOOT DOWN OVER CONNECTOR. POLISH AFTER EPOXY HAS CURED FULLY.

**RECOMMENDED EPOXY:**  
EPO-TEK 301

**CRIMP TOOL:**  
IF 370046  
USE 1.73 [.068\"] HEX CRIMP



Part ID	Hole $\phi$
51 0516	0.51 $\pm$ .01 mm
51 0071	0.255 $\pm$ .005 mm




UNLESS OTHERWISE SPECIFIED  
DIMENSIONS MILLIMETERS [IN.]

DIMENSIONS ARE FOR REFERENCE ONLY  
NO TOLERANCES MAY BE IMPLIED FROM THIS DOCUMENT

PRODUCT	
MATERIAL	Stainless Steel
FINISH	Passivated
DRAWN BY	B. Bidwell
DATE	8/31/2016
CHECKED BY	A. Reyes
DATE	10/10/2016

Industrial Fiber Optics TEMPE, AZ 85281			
<b>500<math>\mu</math>m SMA</b>			
NAME	PART NUMBER		REV
	A	B	B
SIZE	SCALE	PART NUMBER	
A	1:1		
DO NOT SCALE DRAWING			1 OF 1



**METRIC**